

Shaft Coupling

Couplings connect shafts in rotating equipment such as pumps and gearboxes. Some couplings can disconnect when a torque limit is exceeded.

