

Cordless Electric Snow Shovel with Adjustable Chute

This cordless electric snow shovel is designed for effortless snow removal on patios, decks, and walkways. The adjustable throwing chute direction can be easily controlled via a knob, providing precise snow dispersal.



Product Overview

Cordless Efficiency for Winter Maintenance

This cordless electric snow shovel is designed for effortless snow removal on patios, decks, and walkways. Powered by a rechargeable battery, it eliminates the inconvenience of cords while providing portable snow clearing performance. The integration of ergonomic features like a comfortable handle and supportive wheels ensures user ease during operation.

Technical Features

Key Functionality

- HandleShare system for multi-tool platform compatibility
- Adjustable throwing chute controlled via manual knob
- Quick-attachment coupler for tool interchangeability
- Integrated wheels for effortless mobility
- Ergonomic handle for convenient transport

Compatibility

System Compatibility

Multi-Tool Platform, HandleShare System, Quick-Attach Ready

Usage

Recommended Use

Patios • Walkways • Decks