


Cordless Electric Vibrating Floor Mop with Spray

This cordless electric mop uses high-frequency vibration to loosen dirt and grime. It features a rechargeable battery and a water spray function for enhanced cleaning.



ADDITIONAL IMAGES




Overview

Advanced Cordless Vibration Mop

This rechargeable electric cordless vibration mop is designed to revolutionize floor cleaning with high-frequency technology that mimics manual scrubbing. Featuring an integrated water spray system and a slim, maneuverable design, it effortlessly reaches under furniture and into corners. Compatible with various floor types, it provides a versatile and efficient solution for maintaining a hygienic home environment.

Performance



High-frequency vibration technology compared to traditional methods and versatile liquid usage.

Cleaning Efficiency


60 x faster

Speed vs Manual


Vibration Frequency

900 times/min


Design & Ergonomics



Slim body design allows for easy cleaning under furniture and in tight corners.



User-friendly design features including battery status indicators and easy water injection.



Key components including spray switch, power button, and nozzle.

Battery Capacity Indicators

- 100%
- 65%
- 30%

Body Height

10 cm

Control Method

One-hand control

Compatibility


Compatible Liquids

- Clean water
- Polishing oil
- Disinfectant
- Air freshener

Applicable Floor Types

Wooden, Ceramic Tile, Laminate, Marble

Accessories



Multiple pad options and included accessories for various cleaning scenarios.

Cleaning Pad Options

Pad Type	Key Benefit
Disposable	Degradable, no hand wash needed
White Standard	Spiral fibers remove stains, soft fibers absorb moisture
Looped	Terry edge absorbs hair via static