


Pneumatic Tire Valve Core

Valve cores are small, spring-loaded valves used in pneumatic tires. They allow air to be inflated into the tire while preventing air from escaping.



Product Overview

Professional Grade Valve Core

The CPX4012 pneumatic tire valve core is a precision-engineered, spring-loaded component designed for optimal tire inflation control. Built from durable materials, this core ensures a reliable air-tight seal that prevents leakage under various operating conditions. It is an essential component for the maintenance and repair of standard pneumatic tire systems.

Product Details

Model Number	CPX4012
Core Type	Spring-loaded pneumatic

Construction & Compatibility

Suitable For

- Standard pneumatic tires
- Inflation maintenance systems

Material Composition	Brass, Steel
----------------------	--------------

Maintenance

Required Tools	Valve core removal and installation tool
----------------	--